



NOTES

For 40dB install R3, R4, R5, R6, R7, R8. Omit R1
 For 20dB install R1, R5, R8 only. Link R3, R4, R6. Omit R7

TITLE: 20-40dB_RF_Attenuator

Document Number:

REV:

Date: 8/22/14 10:42 AM

Sheet: 1/1